



#### Wheel load scale RW10.1

- operation on or flush with floor
- portable (with suitable handling equipment)

Weighing surface 850 mm x 400 mm  
Platform height 45 mm

Type	Nominal load	Sensitivity / display increments *	Accuracy *	Weight of scale
RW 10.1 / 2000	2000 kg	1 kg	±5 kg up to 400 kg ±10 kg above 400 kg	38.0 kg
RW 10.1 / 8000	8000 kg	5 kg	±20 kg up to 2000 kg ±40 kg above 2000 kg	42.5 kg

\* other accuracies and sensitivities on request